

# Laboratory Report

# Tensile Test

Submitted by: Sakariye Abiikar (Group Leader) K2371673

Sandeep Singh K2314795 Aland Floyd Noronha K2423819 Alan Roy K2314478 Judas Surname K5671234

**Key Dates:** Date of practical:

Deadline: 31/12/2024 Date of submission:



# Contribution Table

Student	Course	Contribution	Picture	
Sakariye Abiikar	Mechanical Engineering	, , , , , , , , , , , , , , , , , , , ,		
Andrew Surname	Aviation	Introduction		
Lucas Surname	Astro	Results		
James Surname	Mechanical Engineering	Discussion, References		
Judas Surname	Civil Engineering	No Contribution		



# **Table of Contents**

1	Abstract	4
2	Introduction	5
3	Method	6
4		7 8 9 9
_	1	10
		12
7	Discussion	14
8	Conclusions	15
9	Recommendations	16
10	References	17
11	A HV (Vickers Hardness)	18 18 19



## 1 Abstract

This study investigated the effects of two thermal treatments on the mechanical properties of HE30/BS1476 aluminium alloy, initially characterized by a hardness of 120 HV5, an elastic modulus of 6 GPa, and an ultimate tensile strength of 500 MPa. The alloy underwent two heat treatments: first, heating for 90 minutes at 520°C, followed by an additional 40 minutes at 184°C in open air. Three distinct alloy variations were produced as a result of these treatments. The aim of the research was to quantify changes in hardness, modulus of elasticity, yield strength, ultimate tensile strength (UTS), and percentage elongation. Hardness was measured using a Zwick Roell ZHU hardness testing machine with a 5 kg load (HV5) (See Appendix A), and properties such as stress and strain were derived from data obtained using a Zwick Roell 2050 tensile testing machine.



### 2 Introduction

In engineering, the selection and optimization of materials directly impact the performance of a design application, especially in aerospace, automotive, and construction industries.

Aluminium alloys have a good strength-to-weight ratio and corrosion resistance; therefore, they are very important in such sectors, though mostly in applications requiring specific mechanical improvements through controlled processes.

Research by metallurgists such as Sorby and Sauveur demonstrated that **heat treatment** significantly improves the properties of alloys. By changing the alloy's microstructure, these heat treatments improve its tensile strength, hardness, and elasticity. Various heat treatment techniques, including quenching and solution heat treatment, are designed to accomplish particular mechanical qualities based on the alloy's intended use.

The **aging process** is a critical aspect of heat treatment, fundamental to precipitation hardening, as highlighted by metallurgists like William Hume-Rothery. It enhances the material's properties by promoting the formation of fine precipitates, which obstruct dislocation movement, thereby increasing the alloy's strength and hardness, it is thoroughly regulated in terms of temperature and time in order to maximise the distribution of these precipitates.

For example, one study applying these strategies involved a solution heat treatment of Al 6082 alloy for 8 hours, resulting in an increase in hardness from 65 BHN to 102 BHN. Additionally, its tensile strength rose from 154 MPa to 280 MPa after 6 hours of aging at 205°C and 495°C (Singh, R., Singh, P., & Das, 2023).

These microstructural enhancements allow aluminium alloys such as HE30 to be used in very demanding applications in the aerospace and automotive industries.

This research work investigates the response of HE30 aluminium alloy to thermal treatments by observing the changes in mechanical properties.



## 3 Method

This laboratory research primarily focused on the evaluation of the mechanical properties of our alloy samples, specifically key metrics such as yield strength, ultimate tensile strength (UTS), modulus of elasticity, hardness, and percentage elongation. These properties are essential for understanding the material's behavior under stress and are typically used to assess the material's suitability for different engineering applications.

The methodology applied in this research was designed around an **integrated testing strategy**—an approach that aims to maximize the amount of data obtained from each step while ensuring the highest level of accuracy and efficiency. This is often referred to as **data-driven experimentation** or **multivariate analysis**, where multiple factors are measured simultaneously to extract a fuller picture of material properties with minimal effort.

The **goal-oriented design** of the methodology is based on the principle of reducing experimental redundancy while maximizing the information gathered. For example, a single tensile test can yield data on multiple properties (e.g., UTS, yield strength, modulus of elasticity) with the help of carefully selected test parameters and data analysis methods.

This principle is at the heart of experimental optimization, often involving methods like **response** surface methodology (RSM) or factorial design, which help streamline the testing process by systematically varying and analyzing input parameters to identify the most efficient experimental conditions.

By focusing on a minimal set of tests that can provide insights into multiple properties, this methodology ensures that each procedure is maximally informative, thus minimizing resource usage and reducing the chances of error.

Our approach was characterized by the following key components:

- 1. Dimensional Analysis
- 2. Hardness Testing
- 3. Tensile Testing
- 4. Data analysis

Note that **Sample Preparation** is distinct from the testing process and is not considered part of the testing itself.

This comprehensive and interconnected approach underscores the efficiency of our laboratory testing methodology. By designing experiments that yield multiple insights from each procedure, we were able to conduct a thorough analysis of the alloy's mechanical properties while minimizing resource usage and potential sources of error. This method not only ensures the accuracy and reliability of our results but also provides a rich dataset for in-depth analysis and interpretation of the alloy's performance characteristics.



# 4 Experimental Procedures

The alloys used in this study are based on the HE30 (BS 1476) aluminium alloy. BS 1476, officially titled "BS 1476:1955 - Wrought Aluminium and Aluminium Alloys for General Engineering Purposes. Bars, Rods, and Sections," was introduced on December 22, 1955, and underwent several revisions reflecting advancements in materials science and engineering practices. The standard's last revision occurred in 1987, and it remained active—with amendments—until its withdrawal on June 21, 2022.

While it is known that BS 1476 is no longer an operational standard, there is no publicly available evidence that it was directly replaced by a specific successor, such as those often published under European Norms (EN).

Although the exact BS 1476 standards for HE30 are hard to come by, the composition and properties of the **6082 aluminium** alloy are often used as a contemporary substitute for HE30 in engineering processes.

### 4.1 Description

Key details are as follows:

Aluminium HE 30 alloy a.k.a AL 6082 is a medium strength alloy with excellent corrosion resistance. It has the highest strength of 6000 (6XXX) series alloys. It is also known as a structural alloy. In block, plate, or bar form, AL HE 30 alloy is most commonly used in machining.

Although it is a relatively new alloy, due to its higher strength, AL HE 30 has replaced AL 6061 in many applications. The addition of a large amount of manganese controls the grain structure which in turn results in a stronger alloy.

#### Characteristics:

- High strength-to-weight ratio makes it ideal for lightweight structures.
- Most versatile and highest strength alloy in the 6000 series Aluminum.
- Good machinability compared to metals like Stainless Steel (SS) and Mild Steel (MS).
- Lightweight and corrosion-resistant components.
- Alternative to plastics in high-stress applications.
- Lower fatigue strength and elastic strength compared to steels.

#### **Applications:**

- Automotive components.
- Electronic applications.
- Aerospace components.
- Trusses, frames, and beams.

 $Source:\ Truventor,\ 27/03/2019$ 



While it is common practice to treat HE30 as equivalent to Aluminium Alloy 6082, minor differences in composition and performance may exist between HE30 under BS 1476 and 6082. For more precise specifications of HE30 under BS 1476, consulting the British Standards Institution (BSI) may provide further clarity, especially since the standard was withdrawn in 2022.

For the purposes of this work, HE30 will be treated as equivalent to 6082, which serves as the basis for further analysis of its properties and related topics, i hope you can understand.

### 4.2 Composition

Chemical Element	% Present
Aluminium (Al)	Remainder
Silicon (Si)	0.7-1.3%
Magnesium (Mg)	0.6-1.2%
Manganese (Mn)	0.4-1.0%
Iron (Fe)	0.5% max
Copper (Cu)	0.1% max
Zinc (Zn)	0.2% max
Chromium (Cr)	$0.25\%~{ m max}$
Titanium (Ti)	0.1% max
Residuals	0.15% max

Table 1: Chemical Composition of 6082 (HE-30) Alloy (Truventor, 2019)

Chemical Element	% Present
Aluminium (Al)	Remainder
Copper (Cu)	0.1% max
Magnesium (Mg)	0.4 - 1.5%
Silicon (Si)	0.6 - 1.3%
Iron (Fe)	$0.6\%~{ m max}$
Manganese (Mn)	0.4 - 1.0%
Zinc (Zn)	0.1% max
Chromium (Cr)	$0.5\%~{ m max}$
Titanium (Ti)	0.2% max

Table 2: Chemical Composition of HE30 according to Dr. Santiago's Data

The composition of HE30 (also known as 6082) generally follows the typical values for 6082 aluminium alloy, as shown in Table 1.

Once again, I stress that there may be minor differences in the composition of HE30, especially in accordance with the BS 1476 specifications.

The values listed here are provided for reference, but the exact composition of the HE30 alloy should be verified for accurate work in our lab, as it may not align with typical web standards.

Although I do have actual information regarding the "Aluminium alloy HE30 BS1476" from Dr. Santiago shown in Table 2, it is important to note that this source lacks proper documentation, and its credibility remains uncertain.

This information contradicts much of the current research surrounding the HE30 BS1476, as i iterated that the standard has been withdrawn and has not been explicitly updated or replaced; it is still mainly unreferenced and not widely recognised in the contemporary literature, as such is why i adopted the 6082.

Although there are slight differences between the two sources in terms of composition, I have chosen to adopt Dr. Santiago's version for the purpose of this work. This decision is based on the fact that the table he provided reflects the information he, as my instructor, has shared with me. While I acknowledge the discrepancies and the lack of clear sourcing in his data, I consider it appropriate to proceed with his version for expediency, particularly as it aligns with the guidance he has given in our coursework.



## 4.3 Heat Treatments and Alloy Conditions

Each sample was treated under different conditions to evaluate the effect of heat treatment on its mechanical properties. The samples were provided in the typical bone-shaped form for tensile testing. The heat treatment conditions are as follows:

- AR (As Received): The sample was used without any heat treatment, in its initial state as supplied.
- ST (Solution Treatment): The sample was heated at 520°C for 90 minutes to dissolve precipitates, improving ductility. The exact quenching method is unspecified.
- PH (Precipitation Hardening): The sample was first heated at 520°C for 90 minutes, followed by aging at 184°C for 40 minutes to enhance strength and hardness.

These treatments were applied to assess how they influence the alloy's mechanical properties.

## 4.4 Equipment List

Equipment Image		Reasoning		
Digital Caliper		Enables precise and accurate measurement of small dimensions, such as the diameter, thickness, and depth of samples, crucial for ensuring consistency in experimental setup and results.		
Vickers Hardness Testing Machine		Used to assess the hardness of materials by applying a standardized force to create an indentation, which is then measured to determine the material's resistance to deformation.		
Zwick Roell 2050 Tensile Testing Machine		Evaluates the tensile strength and mechanical properties of materials under uniaxial tension, providing data essential for material performance analysis and comparison.		
Personal Protective Equipment (PPE): Safety glasses, closed-toe shoes, lab coat		Protects against potential hazards in tensile testing, such as flying debris from specimen fracture, pinch points in the testing machine, and general laboratory risks further shown in Table 4.		
Camera/Smartphone and Stationery		Essential for documenting experimental setups and procedures, capturing visual evidence of results, and recording detailed observations, calculations, and procedural notes for accurate reporting.		

Table 3: Overview of Equipment Used in the Experiment



#### 4.5 Risk Assessment

The experimental procedures involved several potential hazards. The identified risks, their levels, and mitigation strategies are outlined below:

Hazard	Risk	Level of Risk	Control Measures
Sharp edges of dogbone samples	Cuts or injuries while handling samples	Medium	Handle with care; use gloves when measuring and mounting samples.
Tensile testing machine	Pinching or crushing injuries from moving parts	High	Keep hands and body away from moving components during oper- ation; follow machine's safety pro- tocols.
Vickers hardness testing machine	Injury from improper handling or sample misplacement	Medium	Ensure proper training before operation; position samples correctly and keep fingers clear.
General laboratory environment	Slips, trips, and falls due to clutter or spills	Low	Maintain a tidy workspace; clean spills immediately; wear appropriate footwear.

Table 4: Identified hazards, associated risks, levels, and control measures.

## 4.6 Conducting the Experiment

For the experiment, we were provided with three samples, which are visually represented in the image below:




Figure 1: Visual representation of the three samples

Additionally, we were given an A4 sheet with a form to complete, which looked as shown below:






Figure 2: Form for recording sample measurements

On this form, we were required to fill out the values for the width, length, and hardness (measured using the HV5 scale) for each of the three alloys.



# 5 Theory



# 6 Results

Nr	Specimen ID	Date	Stress - Maximum Load (N)	Strain Extension at Break (mm)	Thickness (mm)	Width (mm)	$egin{array}{c} \mathbf{CSA} \\ (\mathbf{mm}^2) \end{array}$
1	ST	20/11/2024	8580	19.8	1	1	1.00
2	РН	20/11/2024	23800	9.8	1	1	1.00
3	AR	20/11/2024	24400	9.7	1	1	1.00

Table 5: Specimen Data




Figure 3: Machine produced data



# 7 Discussion



# 8 Conclusions



# 9 Recommendations



# 10 References

- 1. Singh, P., Singh, R.K. & Das, A.K., (2023) 'Optimization of Heat Treatment Cycle for Cast-Al6082 Alloy to Enhance the Mechanical Properties'. Research Square. Available at: https://assets-eu.researchsquare.com/files/rs-3363991/v1/9cd60f8c-a164-4e0 4-8552-1933478eaded.pdf?c=1711467707 [Accessed 7 December 2024].
- 2. https://truventor.ai/assets/pdf/datasheets/Aluminium



# 11 Appendix

### A HV (Vickers Hardness)

The Vickers hardness (HV) test is a precise and versatile method for evaluating material hardness. It employs a diamond-shaped indenter with a square base and an included angle of 136° between opposing faces. The indenter is pressed into the material under a specific load, typically ranging from 1 to 100 kgf, applied for 10 to 15 seconds.




Figure 4: Diagram showing the diamond-shaped indenter with the 136° angle and diagonals  $d_1$  and  $d_2$ .

The Vickers hardness (HV) is calculated using the applied force (F) and the surface area (A) of the indentation.

$$HV = \frac{F}{A}$$
 (Eq. 1)

- HV: Vickers hardness (dimensionless)
- F: Applied force (kgf or N)
- A: Surface area of the indentation (mm<sup>2</sup>)

The formula for A incorporates the geometry of the diamond pyramid indenter, Such that surface area A can be expressed as:

$$A = \frac{d^2}{2\sin\left(\frac{136^\circ}{2}\right)}$$
 (Eq. 2)

Where:

- A: Surface area of the indentation (mm<sup>2</sup>)
- d: Arithmetic mean of the diagonals  $d_1$  and  $d_2$  (mm)

in so that it is equivalent to:

$$A = \frac{\left(\frac{d_1 + d_2}{2}\right)^2}{2\sin\left(\frac{136^\circ}{2}\right)} \approx 0.1382 \left(d_1 + d_2\right)^2$$
 (Eq. 3)

The HV5 test, for instance, applies a fixed load of 5 kgf (49.03 N), and the hardness is calculated as:

$$HV5 = \frac{49.03}{A} \approx \frac{354.78}{(d_1 + d_2)^2}$$
 (Eq. 4)

The test procedure involves measuring the two diagonals of the indentation under a microscope and squaring their sum. The resulting hardness value is expressed as a dimensionless number, such as HV30, which denotes the hardness under a 30 kgf load.

#### Importance and Applications

The Vickers hardness test is particularly useful for evaluating materials with fine microstructures or thin coatings, as it can accurately measure small indentations. The test's precision and ability to quantify hardness provide critical information about a material's resistance to deformation, making it invaluable for quality control and research in metallurgy, engineering, and materials science.



## B BHN (Brinell Hardness Number)

The Brinell Hardness Number (BHN) measures a material's resistance to deformation, determined by the indentation left by a hard steel or carbide ball pressed into the material under a specified load. This test is commonly used for materials with a coarse or heterogeneous grain structure.

The formula for calculating the Brinell Hardness Number is:

$$BHN = \frac{2P}{\pi D(D - \sqrt{D^2 - d^2})}$$
 (Eq. 5)

Where:

- P: applied load in kilogram-force (kgf),
- D: diameter of the indenter (typically 10 mm),
- d: diameter of the indentation (mm).

**Note**: The Brinell test may use either P or F for the load, depending on the source.

The BHN provides insight into a material's ability to resist wear and deformation, which is important for assessing the durability and suitability of metals in various engineering applications. BHN values are particularly useful for testing larger, rougher materials and are commonly applied to metals like steel and cast iron. The results help predict wear resistance and strength under load.